Lock 'N Safe

OWNER'S MANUAL — Please read before using this equipment.

Use your own personal safe to store precious belongings!

The Lock 'N Safe guards your personal stuff! Use the safe to store your allowance, baseball cards, or play jewelry. The coin slot at the top lets you use the safe as a piggy bank. When you enter a code to open the safe, the buttons flash and the door makes a creaking sound. The Lock 'N Safe is recommended for ages 6 and up.

INSTALLING BATTERIES

Your safe requires three AA batteries (not supplied) for power. For the best performance and longest life, we recommend RadioShack alkaline batteries.

Cautions:

- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, or different types of batteries.

1. Use a Phillips screwdriver to loosen the screw on the battery compartment cover, then lift up the cover.
2. Put the batteries in the compartment as indicated by the polarity symbols (+ and –) marked inside.
3. Replace the cover and tighten the screw.

When the safe stops operating properly, replace the batteries.

Warning: Dispose of old batteries promptly and properly. Do not burn or bury them.

Caution: If you do not plan to use the safe for several weeks, remove the batteries. Batteries can leak chemicals that can destroy electronic parts.

USING THE SAFE

To open the Lock 'N Safe, you must enter a four-digit code. The preset code for the safe is 0000. You can either use the preset code or enter your own.

1. Press **0 0 0 0**. The green indicator lights.
2. Rotate the knob clockwise and pull open the door. You hear creaking sounds. The green indicator lights for about five seconds.

   Note: If you do not open the door within five seconds, the green indicator goes off and the safe is locked again.
3. If you enter the wrong code, the red indicator flashes and two beeps sound. Try entering the code again.
4. When you finish, close the door to lock the safe.

Note: If the door is kept open for more than 20 seconds, the red indicator flashes and the safe beeps twice. The safe continues to beep ev-

© 2001 RadioShack Corporation. All Rights Reserved.
RadioShack and RadioShack.com are trademarks
used by RadioShack Corporation.

RadioShack®

www.radioshack.com℠

ery 20 seconds. Close the safe door to stop the beeping.

CHANGING THE CODE

You can change the code to a number that means something special to you.

1. Enter the currently set code and open the door.
2. Press *. Both the red and green indicators flash and a beep sounds.
3. Enter the new 4-digit code.
4. Press # to store your new code. The red and green indicators stop flashing.

   Note: If you do not enter a new code within about 10 seconds, the red and green indicators stop flashing. Start over from Step 2.
5. Close the door of the safe.

Note: To return the code to 0000, remove the batteries, then press any key on the safe. Replace the batteries. The safe beeps.

CARE

Keep the safe dry; if it gets wet, wipe it dry immediately. Use and store the safe only in normal temperature environments. Handle the safe carefully; do not drop it. Keep the safe away from dust and dirt, and wipe it with a damp cloth occasionally to keep it looking new.

Modifying or tampering with the safe's internal components can cause a malfunction and might invalidate its warranty. If your safe is not performing as it should, take it to your local RadioShack store for assistance.

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.
Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.
In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.
This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.
This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.
RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell *12/99*

60-1215
05A01
Printed in Hong Kong

RadioShack Corporation
Fort Worth, Texas 76102